



## Installation of Nanoptix Ultraboard Configuration Software From Download – Vista or XP

To download the software go to:

<http://www.funcomfg.com/utilities/ultraboardconfig.zip>

When asked to save the file, we suggest the desktop as it's the easiest location to find the file again.

When the download completes, close any programs you may have running such as Word, Internet Explorer, etc.

Go to your desktop, double click on the downloaded file, ultraboardconfig (or it might say ultraboardconfig.zip).

Double click setup (or setup.exe) not setup.lst

Hit OK on the welcome screen

Click on the computer icon to start the install

Press continue on the groups screen

Press OK

To launch the software once installed, go to:

Start / All Programs / Nanoptix / UltraBoard Configuration Utility

If you have any problems installing the Nanoptix software, contact us at 608-565-5558 or toll free 800-808-5554.